

## Reset the fiber optic router



### Overview

Restart or Factory Reset a GFiber Device Discover how to easily restart or factory reset your GFiber device with our step-by-step guide for a How Do I Reset.

### Key Takeaways

You can reset your fiber optic router by performing either a soft restart or a hard factory reset, depending on the severity of your connectivity issues. Soft Reset (Restart)

A soft reset is a simple way to clear minor glitches without erasing your settings:

- Power off the router: Use the power button or unplug the power cable from the router.
- Wait: Pause for 30–60 seconds to allow the router to clear its memory and temporary errors.
- Power on the router: Plug it back in or press the power button.
- Check the lights: Wait until all indicator lights stabilize, indicating the router is fully powered and ready.
- Test your connection: Open a webpage or stream a video to ensure the internet is working properly .

Hard Reset (Factory Reset)

A hard reset restores the router to its original factory settings, erasing Wi-Fi names, passwords, and custom configurations:

- **Locate the reset button:** Usually a small recessed button on the back or bottom of the router. You may need a pin or paperclip to press it .
- **Power off the router:** Unplug the power cable or switch off the device.
- **Press and hold the reset button:** Keep it pressed for 10–15 seconds until the router's lights start flashing or it begins to reboot .
- **Power on the router:** Some routers require you to continue holding the button while powering on; check your device instructions.
- **Release the button:** After the specified time, release the button and allow the router to complete the reboot.
- **Reconfigure network settings:** You will need to set up your Wi-Fi name (SSID), password, and any other custom settings again .

#### Additional Tips

- **Wait for stabilization:** After any reset, give the router a few minutes for all lights to stabilize before testing connectivity .
- **Use the app if available:** Some fiber providers, like Google Fiber, allow you to restart or reset the router via their app, which can simplify the process .
- **Troubleshoot first:** Check your internet speed and connectivity before performing a hard reset, as a soft restart often resolves most issues . By following these steps, you can refresh your fiber optic router, resolve software glitches, and restore stable internet performance.

## Article Content

### How Do I Reset My Fiber Internet for a Quick Fix?

Resetting your fiber internet router can be an effective solution to fix various connection issues. Here are the steps to

### How and When to Reset Your Modem | Quantum Fiber

Learn how to reset your Quantum Fiber modem/router to default settings. The factory reset on a modem should be used with caution.

### How to Reset Your Router in 2026: Soft & Hard Reset

To restart your router (soft reset), unplug the power cable from the wall outlet, wait 30 seconds, then plug it back in.

### How do I reboot / power cycle my Comporium Fiber Internet connection?

To power cycle your fiber internet connection, first, unplug the power cord (thin black cord) for your router. Next, unplug the power

Master Reset Fiber Home, How To

This is the best method to Power Reset Fiber Home. Learn how to set all Fiber Home settings to factory defaults. How to Master

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

## Contact Us

Continue your research online:

Website: <https://coetzerinvestments.co.za>

Technical inquiry: <https://coetzerinvestments.co.za/contact.html>

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

